



VERÇADE
WALL FASHION

ROLL-ON ADHESIVE

- Solvent Free -
- Instant Grab -
- Outstanding Shear Resistance -
- California SCAQMD Rule 1168 Compliant -

1 US Gal. (Net Contents: 8.2 lbs/3.71 kg)

CAUTION: KEEP OUT OF REACH OF CHILDREN

Verçade Roll-On Adhesive is a revolutionary solvent free, easy to use advanced aqueous adhesive suitable for interior installations of Verçade Wall Fashion Tiles and Planks. The adhesive is applied using a 3/8" nap paint roller and dries quickly to facilitate fast installation times. Coverage is approximately 350-400 square feet per gallon. Once Verçade Roll-On Adhesive is dry, the adhesive provides an instant, permanent contact bond when pressure is applied by hand rolling the Verçade Wall Fashion Tiles and Planks. Verçade Roll-On Adhesive is made with an advanced antimicrobial system to protect the adhesive from bacteria and fungal growth. Verçade Roll-On Adhesive is SCAQMD Rule 1168 compliant and conforms to CA Section 01350.

BEFORE YOU BEGIN

Important: Proper preparations are essential. Be sure the work site has proper ventilation during installation. The use of a NIOSH or OSHA-approved dust mask is recommended during the cutting of Verçade with power tools to prevent inhalation. Wear safety glasses.

INSTALLATION CONDITIONS

Verçade is only approved for dry wall installations. Verçade should not be installed on wet-wall applications area's such as shower surrounds and tub walls.

APPROVED SUBSTRATES

Bead board, tile board, Cement board, Concrete (must be smooth, flat, dry and sealed), HardiBacker®, Plywood (must be A.P.A. approved with minimum grade of "BB" or "CC"), Sheetrock/drywall/green board **MUST BE PRIMED or PAINTED** with latex paint and Wood paneling.

NON-APPROVED SUBSTRATES

Brick, Carpets & textiles, Cinder block, Fiberglass, plastics, Glass, Luan, Particle Board, OSB, Vinyl/PVC

SURFACE PREPARATION

CLEAN SUBSTRATE IS ESSENTIAL! All substrates must be clean, smooth, dry and free of waxes, existing adhesives, dirt, dust, grease, oil or sealers. This adhesive cannot be used over chemically cleaned substrates. Surface must be smooth, dry, flat and free of dust and foreign matter. Remove loose paint, wallpaper, old adhesive residue, wax or any other substances that may interfere with the bonding of the adhesive.

- Voids or deviations of 1/4" (6.5 mm) need to be leveled with spackle/joint compound. Follow spackle or joint compound instructions to allow for proper drying time.
- For installations over new drywall you will need to tape and finish the seams where new drywall sheets join together. Drywall sheets are tapered along the long ends, and this needs to be filled for a smooth, flush substrate.
- Remove all electrical plates, vents, and fixtures attached to the wall.

Note: It may be necessary to purchase longer screws when reattaching electric plates or fixtures after Verçade has been installed. The installation site must be acclimatized with HVAC in operation. The wall substrate and room temperature, as well as wall tiles and adhesive, must be maintained at 55°-90°F and the humidity between 40%-65% for 48 hours prior to, during, and after the installation.

APPLICATION

A roll-on application method is required to achieve a smooth even full-spread coating. Spread rate and drying time of the adhesive will depend on the porosity and texture of the substrates and the ambient temperature and relative humidity. **KEEP PAINT ROLLER WET!!** Do not apply pressure to the roller, allow it to freely roll over the substrate. **ADHESIVE COVERAGE MUST NOT EXCEED 400 sq. ft./gallon.** Overly absorbent or rough substrates will require two coats. Once the coating has dried, it must be kept clean and apart from any contact with other surfaces until ready to begin the bonding process. Do not spread more adhesive than can be covered in 4 hours.

INSTALLATION

Once the Verçade Roll-On Adhesive has dried the tiles and planks can be carefully placed into position to achieve a precise tight fit and proper alignment before pressing or rolling the assembly. Once in place, apply pressure using a hand roller to lock tiles in place. When all of the Verçade product is installed, roll the entire assembly in both directions with a hand roller to achieve a full contact bond.

Note: Once the Verçade makes contact with the adhesive and is pressed into position it is not possible to remove it without damaging the substrate or material.

COVERAGE

Approximately 350-400 square feet per gallon when applied with a 3/8" nap paint roller.

CLEAN-UP

Wipe up spills and drips with a clean dampened cloth. Dry adhesive may require the use of denatured alcohol.

PRECAUTIONARY STATEMENTS

In case of eye contact, flush with water for 10-15 minutes. If irritation persists contact a physician. If prolonged skin contact causes irritation, wash with soap and water. If swallowed, consult a physician. Avoid release to the environment. Safety glasses and gloves are recommended if contact is expected.

Dispose of in accordance with local, regional, national, international regulations as specified. Read SDS for detailed product information. SDS may be obtained by calling 844-588-WALL.

24-Hour Emergency in the USA: Chemtrec 1-800-424-9300**SUPPLEMENTAL INFORMATION**

Shelf Life: 2 years from date of manufacture in unopened, properly stored container.

Store indoors at a temperature of 65°-95°F. Protect from freezing. Avoid excessive heat or cold.

Note: Refer to the safety data sheet (SDS) for additional product safety information.

SDS may be obtained by visiting our website at www.vercade.com or by calling 844-588-WALL.

Made in the U.S.A



088969034144

Verçade Wall Fashion
15 Oakwood Avenue
Norwalk, CT 06850
844.588.WALL(9255)

www.vercade.com